

WEINBOX

Flexible wine rack




Wine in its best position

The wine crate serves as both an attractive wine rack and durable transport container. Its robust construction provides excellent protection, and the generous interior dimensions provide sufficient space for the proper storage of twelve standard 750 ml wine bottles. Stacking several crates not only creates an attractive and functional wine rack, but also ensures a clear and orderly arrangement thanks to the label holders on the large doors. The empty wine crate takes up little space and can be collapsed and then conveniently stored or transported.



Properties and advantages

- > clear and orderly arrangement for your wine cellar
- > product protection during transport and storage
- > holds twelve standard 750 ml bottles
- > properly stores wine bottles in a horizontal position
- > easy to set up and take down
(collapsed only 20% of the volume)
- > bottles can be removed from both the front and back sides
when the crates are stacked
- > flexible stackable storage
- > robust and resistant to moisture
- > UV-resistant and safe to wash
- > label holder on the doors
- > Colors: black
- > 100% recyclable



Assembly Instruction

1. Place the bottom of the wine box onto a hard underlay with the smooth surface facing down (ribs up).
 2. Fit the long wall into the hinge shells (hinge openings) of the floor with the smooth side facing outwards. First push slightly downwards and then to the right until the wall audibly locks into place.
 3. Repeat this procedure with the second long wall.
 4. Fit the short wall into the hinge shells (hinge openings) of the floor with the smooth side facing outwards. First push slightly downwards and then to the right until the wall audibly locks into place.
 5. Repeat this procedure with the second short wall.
 6. Turn the assembled wine box over so that the smooth sides of the floor and walls face upwards. Place onto a hard underlay.
 7. Lift a long and a short side upwards to form a right angle (90°).
 8. Place both flaps of the long side into the openings of the short side.
 9. Press the long side outwards and secure (you will hear a "click").
 10. Repeat this procedure with all other sides of the box. The box is then finished.
- A. Lift the opening flap (with label holder) out of the locking.
 - B. Pull the opening flap outwards.



Technical data

Exterior dimensions [mm]	485 x 266 x 247	Dimensions when collapsed, folded outward [mm]	944 x 724 x 17,5
Interior dimensions [mm]	460 x 241 x 228	Total capacity/m ² with 1.92 m staple height and 12 bottles à 0.75 l/box [bottles]	768
Fill volume [l]	25	Delivery units (empty boxes)	Weinbox
Tare weight [g]	1580	Boxes per Euro pallet	204 pcs.
Load capacity [kg]	18	Total height incl. pallet (mm)	1900
Compressive strength when stacked [kg]	500	Color	black
Layer height of empties [mm]	12	Material	PP